
JR (Japan Radio) FM Trainer Cord

by Tony van Roon



Additional Notes

The ground (or shield) wire can be a regular wire but usually is braided. Cable length should not exceed 12 feet.

Wire and Shield are wired straight through, nothing crossed.

Do NOT add a battery of any kind to the buddy box (unless otherwise stated in the manual); because, in general, the buddy box does not need power since only the sticks are used and are powered via the main transmitter. If you do so anyway you're almost certain to blow the fuse (looks like a transistor) and this will likely be a \$40 shop repair. Also, make sure the switches for yes/no reversing the aileron, rudder, trottle, elevator, etc. are identical on the buddy box.

Back to <u>Gadgets Menu</u> Copyright © Tony van Roon